
■ MODELS:AJ*108LALBH, AJ*126LALBH, AJ*144LALBH, AJ*162LALBH



*1: NOTE

X1, X2 : To be connected to indoor unit Z1, Z2 : To be connected to other master outdoor unit

H1, H2: To be connected to outdoor unit within same refrigerant system