



# PARTS

OUTDOOR UNIT  
AOYG36LBLA5  
AOYG45LBLA6





Ref.	Description	Part number
1	Adapter K Assy	9379963022
2	Adapter L Assy	9379963039
3	Adapter H	9379681001
4	Drain Cap	313166024302
5	Drain Assy	9303029015
6	Thermistor Holder	9332505009
7	Protective Net Rear	9381013005
8	Protective Net Left	9381014002
9	Cabinet Left	9380968009
10	Cabinet Right Sub Assy	9380570035





OUTDOOR UNIT  
AOYG36LBLA5  
AOYG45LBLA6

Ref.	Description	Part number
11	Union Cover	9382204006
12	Top Panel Sub Assy	9379416030
13	Front Panel Sub Assy	9380569039
14	Service Panel Sub Assy	9380571032
15	FUJITSU Label	9380477006
16	Propeller Fan	9379414005
17	Fan Motor	9603496012


Ref.	Description	Part number
18	Front Panel	9381023004
19	FRE T3 100 x 3	9375620042
20	Blow Grill	9380955009
21	Insulation Grill R	9380954002
22	Insulation Grill T	9377800497
23	FRE T5 450 x 20	9380956006



OUTDOOR UNIT  
 AOYG36LBLA5  
 AOYG45LBLA6




Ref.	Description	Part number	
21	Thermistor Assy	9900922016	
22	Heat Ex. Thermistor	9900923013	
23	Outdoor Thermistor	9900565046	
24	Duct A	9380961000	
25	Duct D	9380959007	




OUTDOOR UNIT  
 AOYG36LBLA5  
 AOYG45LBLA6  
 Inverter assy


Ref.	Description	Parts number
31	Heat Sink A	9380483007
32	Heat Sink C	9380980018
33	Terminal 2P Power	9900428105
34	Terminal 3P Inner	9306489045
35	Main PCB (36LBLA5)	9710455049
35	Main PCB (45LBLA6)	9710455056
36	Filter PCB	9709911075
37	Transistor PCB	9709901113
38	ACTPM	9708920009
39	Choke Coil	9900624019




Ref.	Description	Part number
41	Condenser Sub Assy	9374420360
42	Condensing Pipe Assy	9371378107
43	3-way Valve Assy	9381055012

OUTDOOR UNIT  
 AOYG36LBLA5  
 AOYG45LBLA6






51




54



OUTDOOR UNIT  
 AOYG36LBLA5  
 AOYG45LBLA6

Ref.	Description	Part number
51	3-way Valve Assy	9315414052
52	Accumulator Sub Assy	9372700075
53	Suction Pipe Assy	9372514191
54	Compressor	9810275004
-	Belt Heater	9361140356








OUTDOOR UNIT  
 AOYG36LBLA5  
 AOYG45LBLA6

Ref.	Description	Part number	
61	Solenoid	9970110146	
62	4-way Valve Assy	9374425594	
63	Sensor	9970158018	
64	Solenoid	9970165016	
65	Solenoid Valve Assy	9380016038	


OUTDOOR UNIT  
AOYG45LBLA6  
Valve unit sub assy




Union plate  
assy-6




Union  
holder



8 pin



9 pin



9 pin

Ref.	Description	Part number
81	Valve Gas Pipe Assy-6	9382236021
82	Valve Liquid Pipe Assy-6	9382235024
83	Expansion Valve Coil A	9970186004
84	Expansion Valve Coil B	9970187001
85	Expansion Valve Coil C	9970186011
86	Expansion Valve Coil D	9970187018
87	Expansion Valve Coil E	9970186028
88	Expansion Valve Coil F	9970187025
89	Thermistor BA Assy	9900924010
90	Thermistor DC Assy	9900925017
91	Thermistor FE Assy	9900939014