
FUJITSU GENERAL LIMITED

## Model: ARXC096GTEH




Front view

INDOOR UNITS


## Installation space requirement

## Unit: mm

 When service access will be carried out above the indoor unit, a recommended installation space of 450 mm is required.




• Installation by which service is carried out from the bottom of the unit.



## Maintenance space requirement

For future maintenance and service access, provide sufficient maintenance space.

**NOTE:** Do not place any wiring or illumination in the maintenance space, as they will impede service.





Unit: mm