


■ Model: ARXD018GLEH


Unit: mm




Rear view




View A




Top view



Side view



Front view



Bottom view


INDOOR
UNITS

INDOOR
UNITS


Installation space requirement

Unit: mm

In ceiling-concealed installations:



In wall-concealed installations:



INDOOR
UNITS


INDOOR
UNITS

■ Maintenance space requirement

For future maintenance and service access, provide sufficient maintenance space.

NOTE: Do not place any wiring or illumination in the maintenance space, as they will impede service.

Unit: mm



INDOOR
UNITS

INDOOR
UNITS