11. Accessories

11-1. Model: ARYG24LMLA

Part name	Exterior	Q'ty	Part name	Exterior	Q'ty
Operating manual		1	Remote controller		1
Installation manual (For indoor unit)		1	Remote controller cable		1
Hanger	LA-A-	4	Screw	and the second s	2
Drain hose insulation		1	Coupler heat insulation (large)	0	1
Cable tie (large)	0	1	Coupler heat insulation (small)	0	1
Cable tie (small)	<u>@</u>	1	Special Nut A (large flange)		4
Cable tie	3	2	Special Nut B (small flange)	8	4
Wire clamper		1			

12. Optional parts

12-1. Controllers

Exterior	Part name	Model name	Summary
	Wired remote controller	UTY-RVNYM	Large and full-dot liquid crystal screen, wide and large keys easy to press, user-intuitive arrow key. Wire type: Polar 3-wire
	Wired remote controller	UTY-RNNYM	Room temperature can be controlled by detecting the temperature accurately with built-in thermo sensor. Wire type: Polar 3-wire
	Simple remote controller	UTY-RSNYM	Compact remote controller concentrates on the basic functions such as Start/Stop, fan control, temperature setting, and operation mode. Wire type: Polar 3-wire
	IR receiver kit with wireless remote controller	UTY-LRHYM	Unit control is performed by wireless remote controller.

NOTE: Available functions may differ by the remote controller. For details, refer to the operation manual.

12-2. Others

Exterior	Part name	Model name	Summary	
(×1) (×2) (×1) (×2)	External control set	UTD-ECS5A	Use to connect with various peripheral devices and air conditioner PCB. (Set of 6)	
	Remote sensor unit	UTY-XSZX	Thermo-sensor for sensing the temperature of arbitrary place in the room.	
40 mm	Square flange	UTD-SF045T	Both the Square flange and the Round flange can be selected. Round flange is also used when the fresh-air duct is installed.	
um 261 85 mm	Round flange	UTD-RF204		
507 mm	Long-life filter	UTD-LF25NA	Long-life filter can be mounted to the indoor unit.	
	Drain pump unit	UTZ-PX1NBA	Optional drain lift up mechanism allows more flexible installation.	