



3-5. Wiring diagrams

Model: UTP-RX01AH




POSITION OF SOLENOID COIL




SUCTION GAS PIPE (TO OUTDOOR UNIT) DISCHARGE GAS PIPE (TO OUTDOOR UNIT)

Model: UTP-RX01BH



POSITION OF SOLENOID COIL



SUCTION GAS PIPE (TO OUTDOOR UNIT) DISCHARGE GAS PIPE (TO OUTDOOR UNIT)